

# 66E SERIES COMBINATION LOCK MANAGER OPERATING INSTRUCTIONS

Enter each digit SLOWLY and DISTINCTLY. The lock signals at each entry.

### TO ADD NEW USER

- Enter MANAGER combination. HOLD DOWN LAST DIGIT OF COMBINATION UNTIL LOCK SIGNALS WITH DOUBLE BEEP <u>AGAIN</u> AND LED STAYS ON.
- Press 1. Lock signals twice.
- PRESS NEW USER ID No. (i.e. 6) Lock signals twice.
- New user enters their own 6 digit combination <u>twice</u>. Lock signals twice after each valid entry.
- New user is now active.

### TO DISABLE USER

- Enter MANAGER combination. HOLD DOWN LAST DIGIT OF COMBINATION UNTIL LOCK SIGNALS WITH DOUBLE BEEP <u>AGAIN</u> AND LED STAYS ON.
- Press 2. Lock signals twice.
- PRESS USER ID No. (i.e. 6) Lock signals once. User is now temporarily disabled.

### TO RE-INSTATE DISABLED USER

- Enter MANAGER combination. HOLD DOWN LAST DIGIT OF COMBINATION UNTIL LOCK SIGNALS WITH DOUBLE BLEEP <u>AGAIN</u> AND LED STAYS ON.
- Press 1. Lock signals twice.
- PRESS USER ID No. (i.e. 6) Lock signals once. User is now reinstated.

### TO REMOVE USER

- Enter MANAGER combination. HOLD DOWN LAST DIGIT OF COMBINATION UNTIL LOCK SIGNALS WITH DOUBLE BEEP <u>AGAIN</u> AND LED STAYS ON.
- Press 3. Lock signals twice.
- PRESS USER ID No. (i.e. 6) Lock signals once. User is now permanently removed.



# 66E SERIES COMBINATION LOCK MANAGER OPERATING INSTRUCTIONS

## CHANGING BATTERY (Use only alkaline batteries)

Repeated beeping during an opening indicates that the battery is low.

- Pull off battery cover.
- Replace battery(ies)
- Replace cover.

### TO EXTRACT AUDIT FILE

First, prepare your computer and click the safe icon. Plug the tag reader into the input pad.

- Enter MANAGER code. HOLD DOWN LAST DIGIT OF COMBINATION UNTIL THE LOCK SIGNALS WITH DOUBLE BEEP <u>AGAIN</u>. THE LED WILL NOW COME ON.
- Press 7 to send audit file to computer.

### TO CHANGE MANAGER CODE

- Enter 6 zeros lock beeps TWICE
- Enter current Manager Code lock beeps TWICE
- Enter new 6 digit code lock beeps TWICE
- Enter new 6 digit code again lock beeps TWICE

### MANAGER CODE IS NOW RESET