



Opening the key storage compartment door **A**

1. Before trying to enter your code, always press down the "CLEAR" button, to return all the buttons to their original settings.
2. Enter your code and press down "OPEN" button.
3. If you have entered an incorrect combination, push down the "CLEAR" button to return the buttons to their original settings, then enter your combination

Closing the key storage compartment door **A**

1. Press down the "CLEAR" button
2. Enter your combination, press down and hold the "OPEN" button until you close the door
3. Once the door is closed, release the "OPEN" button

To set a combination **B** **C**

Note that each number in a combination can only be used once.

1. There's no pre-set combination, press down the "CLEAR" button and the "OPEN" button.
2. Open the compartment door and take the white card which is a change tool (to use like a screwdriver) to set combination
3. Behind the door, there are 12 screws (numbered from 0 to 9 and letters A and B) with an arrow. All arrows are set to the "SET OFF" position
4. Use the change tool to turn the numbers you selected (to the left or right) by 180° (1/2 turn) to the "SET ON" position

Your combination is now set, be sure to record it in a safe location

To hang wall mount model:

1. Open the compartment door (see instructions above)
2. Position the lock on the desired surface
3. Use level to verify the lock is vertical
4. Mark the position of the screw holes on the surface
5. Remove lock
6. Drill holes
7. If necessary, use hammer to place anchors
8. Position lock, insert thermoplastic cover flaps behind lock
9. Insert and tighten screws
10. Close the door, position thermoplastic cover on safe for greater weathertough protection