

Electronic Combination Lock

Installation Guide

- Step 9** Select the cam which suits your door and frame and attach it to the square shaft at the end of the spindle.
- Step 10** Now check the operation of the lock using the factory User Code 22 44.
- Step 11** If the lock is functioning correctly, CHANGE THE DEFAULT MASTER CODE xx xx xx and program the lock using the programming and operating instructions enclosed.

B) New Installation

- Step 1** Place template on door and mark upper 6mm (¼") hole and lower 16mm (⅝") hole.

IMPORTANT NOTE: Before drilling fixing holes, please ensure that the position of the combination lock when fitted will allow clearance for selected cam to work.

- Step 2** Drill both fixing holes.
- Step 3** Continue installation from step 4 to 11, above.

A) Replacing existing cam lock with the Combination Lock

- Step 1** Remove existing cam lock.
- Step 2** Place template over hole left by cam lock and mark upper fixing hole.
- Step 3** Drill the 6mm (¼") upper fixing hole.
- Step 4** Fit the Combination Lock to the door by passing the spindle through the 16mm (⅝") hole.
- Step 5** If required, from the inside of the door, pass either of the packing pieces over the spindle to centralise the lock.
- Step 6** Now secure the lock by threading the large nut onto the spindle.
- Step 7** Fit one of the upper fixing bolts to suit your door thickness.
- Step 8** Tighten the lower fixing nut and upper bolt.


Fitting Instructions

The Combination Lock can be fitted to:


- A) Cupboards, combinations and lockers etc as a direct replacement for existing cam locks.
- B) It can also be easily fitted to cupboards and combinations that do not have an existing locking device.

Special Notes

- Before installing the lock, load the batteries and familiarise yourself with the operation and programming.
- The handle will not turn until you enter the factory default Master Code xx xx xx OR the default User Code 22 44.
- Please see programming guide to set your own codes.



ELECTRONIC COMBINATION LOCK INSTALLATION TEMPLATE



↓
TOP

NOTE: PLEASE CHECK SIZES ARE CORRECT BEFORE DRILLING